

# Schlage/Locknetics - CM Series Locks



## CM = Computer Managed

Battery-operated, self-contained locks

- No wires, battery operated
- Program the locks from either laptop or PDA
- Audit trail can be downloaded to laptop or PDA
- Use LockLink or LockLink Express software to program locks

## Setup

You decide the security level, number of users and access types of your system. That system is then setup in the software package, which is installed on either a laptop or PDA.

To implement your system, you travel from lock to lock and download the system using the cable supplied with the software.

The same cable is used to transfer audit trail information back to the laptop or PDA.

Example: You have 4 CM locks in your system.

1. Assign lock numbers to each lock (1 - 4).

2. Assign each user a number (101 - 120 for example).



3. Determine which users need access to which locks and designate them using the software.

4. Transfer your new system to each lock.

## Flexibility

The CM system allows many options in both the hardware and software.

**Hardware:** The locks can be ordered with various access methods, including keypad, iButton, keyed cylinder, prox reader and magnetic stripe. You decide how you want to mix and match these options.

**Software:** You program your system to be as simple or complex as required. Following are some of the software options available to you...

**Users:** Up to 1000 users.

**User Types:** Standard, guest, janitorial, VIP

**Timed Functions:** Program access times, auto lock and unlock and even holiday periods.



In short, the system is designed to allow you all the options you may need, from a simple controlled entry system to a high security system.