


ELECTRIC HINGES	BASICS
 <p>No. Wires Available:</p> <ul style="list-style-type: none"> 4 Wires 6 Wires 8 Wires 10 Wires 	<p>Manufacturer: ACSI</p> <p>Note: ACSI buys hinges from manufacturers and then adds wires to electrify the hinges at their shop.</p>

HOW TO ORDER	NOTES																																								
<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 25%;"><u>ACSI</u></td> <td style="text-align: center; width: 25%;"><u>BB1279</u></td> <td style="text-align: center; width: 25%;"><u>4545</u></td> <td style="text-align: center; width: 25%;"><u>26D</u></td> <td style="text-align: center; width: 25%;"><u>1104</u></td> </tr> <tr> <td style="text-align: center;"><u>BRAND</u></td> <td></td> <td></td> <td style="text-align: center;"><u>FINISH</u></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;"><u>MODELS</u></td> <td style="text-align: center;"><u>SIZE</u></td> <td></td> <td style="text-align: center;"><u>NO. WIRES</u></td> </tr> <tr> <td></td> <td>BB1168</td> <td>44 = 4.0 x 4.0</td> <td></td> <td>1104 = 4 Wires</td> </tr> <tr> <td></td> <td>BB1191</td> <td>454 = 4.5 x 4.0</td> <td></td> <td>1106 = 6 Wires</td> </tr> <tr> <td></td> <td>BB1279</td> <td>4545 = 4.5 x 4.5</td> <td></td> <td>1108 = 8 Wires</td> </tr> <tr> <td></td> <td>FBB179</td> <td>545 = 5.0 x 4.5</td> <td></td> <td>1110 = 10 Wires</td> </tr> <tr> <td></td> <td></td> <td>55 = 5.0 x 5.0</td> <td></td> <td></td> </tr> </table>	<u>ACSI</u>	<u>BB1279</u>	<u>4545</u>	<u>26D</u>	<u>1104</u>	<u>BRAND</u>			<u>FINISH</u>			<u>MODELS</u>	<u>SIZE</u>		<u>NO. WIRES</u>		BB1168	44 = 4.0 x 4.0		1104 = 4 Wires		BB1191	454 = 4.5 x 4.0		1106 = 6 Wires		BB1279	4545 = 4.5 x 4.5		1108 = 8 Wires		FBB179	545 = 5.0 x 4.5		1110 = 10 Wires			55 = 5.0 x 5.0			<p>Model Numbers:</p> <p>Hager Models: BB1168 - heavy wt. BB1191 - std. wt. BB1279 - std. Wt.</p> <p>Stanley Models: FBB179 - std. wt.</p>
<u>ACSI</u>	<u>BB1279</u>	<u>4545</u>	<u>26D</u>	<u>1104</u>																																					
<u>BRAND</u>			<u>FINISH</u>																																						
	<u>MODELS</u>	<u>SIZE</u>		<u>NO. WIRES</u>																																					
	BB1168	44 = 4.0 x 4.0		1104 = 4 Wires																																					
	BB1191	454 = 4.5 x 4.0		1106 = 6 Wires																																					
	BB1279	4545 = 4.5 x 4.5		1108 = 8 Wires																																					
	FBB179	545 = 5.0 x 4.5		1110 = 10 Wires																																					
		55 = 5.0 x 5.0																																							

TIPS	NOTES
<p>Most electrified locks require only 2 wires. If the lock has a signal switch as well, it will require 4 total.</p> <p>The same is true with panic devices, except some brands (Von Duprin) require heavier gauge wire. This is because the larger solenoid needs more amps. You can twist 2 wires together to make one heavier wire. Order a 4 wire hinge to make 2 heavy gauge wires.</p>	<p>Wire Gauge:</p> <p>26 ga. wire is standard. Max. electrical rating for 26 ga. is 30 VDC @ 0.500 amps.</p>